

CHAPTER 11


RADIUS Setup

11.1 Introduction

Remote Authentication Dial-In User Service (RADIUS) is a security authentication client/server protocol widely used by Internet service providers on other remote access service. RADIUS is the most common means of authenticating and authorizing dial-up and tunnelled network users.


The built-in RADIUS client function allows you to extend the remote dial-in user accounts to the RADIUS server. Your user accounts will not be limited by built-in accounts. It also lets you centralize remote access authentication for network management. Use the following setup link on the Setup Main Menu to configure the RADIUS function.

Advanced Setup > RADIUS Setup



RADIUS Setup

11.2 Configuration



> Advanced Setup > RADIUS Setup

RADIUS Setup

☐ Enable

Server IP Address

Destination Port

Shared Secret

Re-type Shared Secret

Cancel Clear OK

Copyright (c) 2004, DrayTek Corp. All Rights Reserved.

Check the **Enable** box to enable RADIUS client function

Server IP Address: The IP address of RADIUS server

Destination Port: The UDP port number which the RADIUS server is listening. The default value of 1812 is based on RFC 2138.

Shared Secret: The RADIUS server and client share a secret that is used to authenticate the messages sent between them. You must configure both sides to use the same shared secret.

Re-type Shared Secret: Confirm the Shared Secret.